Site Utility Starter Pack User Guide

UPDATED ON 2/5/2019

PlanSwift

Authored by: Dave Hansen



Table of Contents

Overview	3
Purchasing and Installation	4
Purchasing Plugins	4
Installation and Uninstallation	4
Features	4
How To	5
How to: Copy and Paste an Assembly	5
How to: Copy and Paste Parts	10
How to: Drag and Drop Parts	14
FAQ	
Compendium	17
Site Utility Assemblies	17
Site Utility—Water Assemblies	17
Site Utility—Fire Assemblies	47
Site Utility—Sewer Assemblies	48
Site Utility—Drainage	64

Overview

This guide will teach you how to properly use the tools and features found within the Site Utility Starter Pack. It is designed for use with PlanSwift® Takeoff and Estimating Software. This guide is not meant to be a step-by-step "walk through" document, although it can be used as a reference for getting the work done. If you encounter technical difficulty, consult this guide (including the <u>FAQ</u> section of this user manual) or contact the technical support department at:

PlanSwift® Technical Support <u>support@PlanSwift.com</u> 1-888-752-6794 Ext. 2

PlanSwift also offers additional training. For training options, contact the training department at:

PlanSwift® Training Department training@PlanSwift.com

1-888-752-6794 Ext. 4

Purchasing and Installation

Purchasing Plugins

If you need to purchase PlanSwift or a plugin product, contact the Sales Department at:

PlanSwift® Sales sales@PlanSwift.com 1-888-752-6794 Ext. 1

Installation and Uninstallation

Installing and uninstalling starter packs is simple. For installing them, click on the Import Plugin Package icon (arrow 1 in Figure 1) from the PlanSwift Main Ribbon-bar **Plugin** tab (arrow 3 of Figure 1) and follow the prompts from there. For uninstalling, click on the Uninstall Plugin (arrow 2 in Figure 1) and follow those prompts.



Figure 1

Features

The Site Utility Starter Pack includes Site Utility Assemblies (<u>Water</u>, <u>Fire</u>, <u>Sewer</u>, and <u>Storm Drain</u>) found in the Templates tab of PlanSwift. These are listed in the <u>Compendium</u> at the end of this guide. With these site utility assemblies and parts, PlanSwift users can easily customize assemblies and parts for later use. Starter Packs contain a large library of prebuilt templates, parts and assemblies. Modifying the library of parts and assemblies for any Starter Pack allows users the ability to

customize their Templates to their specific needs. Users will save countless hours of setup by utilizing a Starter Pack as their starting point for building custom parts and assemblies. The instructions below will guide new users through the basics of modifying parts and assemblies. We highly recommend purchasing a training package for accelerated learning and faster customization.

How To

How to: Copy and Paste an Assembly

The purpose of copying and pasting an assembly is to allow the user to copy and then modify the assembly for later use. As an example, you may want two different assemblies: one might include a part, and another might have an alternative part or not include that part at all. By copying one assembly and then modifying and renaming the copy (for easy identification), you can have two different assemblies available, allowing for easier and faster takeoffs. Figure 2 shows the **Templates Tab** (arrow 1) and the **Area Takeoff Item Example 1** assembly (arrow 2). If you want to add another assembly but with no **Material 3**, then you would click on the assembly you want to copy (arrow 2), click on **Copy** (arrow 3), and then click on **Paste** (arrow 4).




Figure 2

Figure 3 shows the original (arrows 1) and new **Area Takeoff Item Example 1** assembly (arrow 2). To delete the **Material 3** (arrow 3) from the newly created **Area Takeoff Item Example 1** assembly (arrow 2), click on **Material 3** (arrow 3), click on **Delete** (arrow 4), and click on **OK** in the popup window to confirm the deletion.




Figure 3

Figure 4 now shows the two assemblies, one with (arrow 1) and one without (arrow 2) the **Material 3** item. You can now change the description of the duplicated **Area Takeoff Item Example 1** (arrow 3) without the **Material 3** item by double-clicking the duplicate **Area Takeoff Item Example 1** (arrow 3).




Figure 4

This opens the **Properties** – [Area Takeoff Item Example 1] window (Figure 5) where you can change the assembly's name to something like Area Takeoff Item Example 1— **No Material 3** to make it easier to identify.




Figure 5

Click on **Ok** in the **Properties** window after you have entered the name. Figure 6 shows the new name.




Figure 6

To perform a takeoff with the **Area Takeoff Item Example 1—No Material 3** assembly, go to the takeoff page, click on the green **Record Button** (see the arrow in Figure 7) in the **Templates** sidebar window, and then proceed to do your takeoff.




Figure 7

Disclaimer

Any modifications that a user makes to a Starter Pack should always be tested and verified by that user to ensure quantities and calculations are accurate. PlanSwift cannot verify the accuracy of modifications made to templates, parts and assemblies by the user.

How to: Copy and Paste Parts

Copying and pasting parts is handled similarly to copying and pasting an assembly. If, for instance, you want to move **Material 6** in **Area Takeoff Item Example 2** to **Area Takeoff Item Example 1**, click on **Material 6** (arrow 1), then click on copy (arrow 2) as shown in Figure 8.




Figure 8

There are now two ways to paste the part. The first is to paste it at the same hierarchical level of a selected item, and the second is to paste it as a sub-item of a selected item. Figure 9 shows the **Paste** button. Clicking on the top half of the button pastes the part at the same hierarchical level of a selected item. Clicking on the dropdown half of the button, then selecting **As Sub-Item** pastes the part as a sub-item of the selected item.




Figure 9

Click on **Area Takeoff Item Example 1**, then click on the top half of **Paste**. As shown in Figure 10, **Material 6** gets pasted at the same hierarchical level as **Area Takeoff Item Example 1**.




Figure 10

If you had selected the drop-down half of the **Paste** button, then **Material 6** would be a sub-item of **Area Takeoff Item Example 1**. Figure 11 shows **Material 6** as a sub-item.




Figure 11

Another way to adjust the hierarchy of an item, such as **Material 6**, is to use the Main Ribbon bar arrow **Adjust** keys (Figure 12).




Figure 12

The left and right **Adjust** arrows move the item left and right (up or down) in the hierarchy, and the up and down **Adjust** arrows keys moves the item higher and lower in the list of items.

A shortcut to the **Copy** and **Paste** and **Past as Sub-Item** selections is available with a right-click menu. Figure 13 shows the **Copy**, **Paste**, and **Paste As Sub-Item** options on the right-click menu when **Material 6** is right-clicked on.




Figure 13

Double-clicking on **Material 6** allows you to change the name of the item and alter other properties of the item (Figure 14). To change the name of **Material 6**, double-click on the **Material 6** name, type the new name, and click on **Ok**.




Figure 14

Figure 15 shows Material 6 renamed to Material 6A.




Figure 15

Disclaimer

Any modifications that a user makes to a Starter Pack should always be tested and verified by that user to ensure quantities and calculations are accurate. PlanSwift cannot verify the accuracy of modifications made to templates, parts and assemblies by the user.

How to: Drag and Drop Parts

Parts may be dragged and dropped from one assembly to another assembly. If, for instance, you want to drag the Material 8 item from Area Takeoff Item Example 2 up to Area Takeoff Item Example 1, click on Material 8 and drag it up to just below Material 6A (see Figure 16) and release the mouse button.




Figure 16

Notice that dragging the part this way *moves* the part from the **Example 2** assembly to the **Example 1** assembly, *not* leaving behind a copy.

The **Templates** sidebar window is a summarized view of everything in the Templates Tab. It is designed for easily dragging and dropping parts and for quickly launching takeoff templates and assemblies.

Parts may be dragged over from the **Templates** sidebar window into the **Templates Tab** window; note that dragging any part from the **Templates** sidebar window makes a copy of it. If, for instance, you want a **Material 7** item added to **Area Takeoff Item Example 1** as a sub-item, simply drag the **Material 7** from the right **Templates** sidebar window over on top of **Area Takeoff Item Example 1** label and release the mouse button. (Figure 17).




Figure 17

Figure 17 shows the Material 7 item in place after it was dropped on top of Area Takeoff Item Example 1. In addition, the Properties – [Material 7] window automatically opens, allowing the user to change any properties for Material 7. Click on Ok to close the Properties – [Material 7] window.

Disclaimer

Any modifications that a user makes to a Starter Pack should always be tested and verified by that user to ensure quantities and calculations are accurate. PlanSwift cannot verify the accuracy of modifications made to templates, parts and assemblies by the user.

FAQ

Question: I've read this user guide, and I still have questions. What do I do?

Answer: We highly recommend new users purchase a training package because training is customized to each user. We offer <u>one-on-one training</u> and <u>classroom training</u>. Contact <u>training@PlanSwift.com</u> or at 1-888-752-6794 Ext. 4.

Question: Does the Starter Pack include everything a contractor will need to generate an estimate?

Answer: No. A Starter Pack is a tool to get you started toward creating a complete estimate. For example, the Starter Pack does not include industry pricing for materials and labor. However, you can supply prices for materials and labor on the assemblies and labor included in the Starter Pack.


Question: Do I have to input all the pricing for all my parts?


Answer: Inputting pricing is optional. You can use the Starter Pack to generate quantities that you can then send to your supplier, who can then provide you current pricing. Inputting pricing on your own is optional. If your industry's pricing is not subject to frequent changes, you may want to consider inputting your pricing in PlanSwift.

Compendium


Site Utility Assemblies

Site Utility—Water Assemblies






Name		Description	Color
⊟ 🛅 DIP			
	3" DIP C52 TJ	3" DIP C52 TJ	
	3" x 18' DIP C52 TJ	3" x 18' DIP C52 TJ	
-	Pipe Laying Labor		
	4" DIP C52 TJ	4" DIP C52 TJ	
	4" x 18' DIP C52 TJ	4" x 18' DIP C52 TJ	
	Pipe Laying Labor		
	6" DIP C52 TJ	6" DIP C52 TJ	
	6" x 18' DIP C52 TJ	6" x 18' DIP C52 TJ	
	Pipe Laying Labor		
	8" DIP C52 TJ	8" DIP C52 TJ	
	8" x 18' DIP C52 TJ	8" x 18' DIP C52 TJ	
	Pipe Laying Labor		
	10" DIP C52 TJ	10" DIP C52 TJ	
	■ 10" x 18' DIP C52 TJ	10" x 18' DIP C52 T.	
	Pipe Laying Labor		
	12" DIP C52 TJ	12" DIP C52 TJ	
	12" x 18' DIP C52 TJ	12" x 18' DIP C52 T.	
	Pipe Laying Labor		
	14" DIP C52 TJ	14" DIP C52 TJ	
	14" x 18' DIP C52 TJ	14" x 18' DIP C52 T.	
<i> </i>	Pipe Laying Labor		
	16" DIP C52 TJ	16" DIP C52 TJ	
	■ 16" x 18' DIP C52 TJ	16" x 18' DIP C52 T.	
<i> </i>	Pipe Laying Labor		
	18" DIP C52 TJ	18" DIP C52 TJ	
	▶ 18" x 18' DIP C52 TJ	18" x 18' DIP C52 TI	
	Pipe Laying Labor		
	20" DIP C52 TJ	20" DIP C52 TJ	
	20" x 18' DIP C52 TJ	20" x 18' DIP C52 T.	
	Pipe Laying Labor		
	24" DIP C52 TJ	24" DIP C52 TJ	
	24" x 18' DIP C52 TJ	24" x 18' DIP C52 T.	
	Pipe Laying Labor		
	30" DIP C52 TJ	30" DIP C52 TJ	
	30" x 18' DIP C52 TJ	30" x 18' DIP C52 T.	
	Pipe Laying Labor		
	36" DIP C52 TJ	36" DIP C52 TJ	
	36" x 18' DIP C52 TJ	36" x 18' DIP C52 T.	
	Pipe Laying Labor		
	42" DIP C52 TJ	42" DIP C52 TJ	
	42" x 18' DIP C52 TJ	42" x 18' DIP C52 T.	
	Pipe Laying Labor		
	48" DIP C52 TJ	48" DIP C52 TJ	
	48" x 20' DIP C52 TJ	48" x 20' DIP C52 T.	
	Pipe Laying Labor		












Name		Description	Color
	1-1/4 Deg. Elbow		
	4" 11-1/4 Deg. Elbow GKT x GKT PVC DR-18 C90		
	11-1/4 Deg. GKT x GKT PVC Bend		
	Fitting Installation Labor		
	···· 💷 No Restraint		
⊟ :•	6" 11-1/4 Deg. Elbow GKT x GKT PVC DR-18 C90		
	11-1/4 Deg. GKT x GKT PVC Bend		
	···· 🕮 No Restraint		
	Fitting Installation Labor		
⊟ .	8" 11-1/4 Deg. Elbow GKT x GKT PVC DR-18 C90		
	11-1/4 Deg. GKT x GKT PVC Bend		
	Fitting Installation Labor		
	■ No Restraint		
<u> </u>	10" 11-1/4 Deg. Elbow GKT x GKT PVC DR-18 C9		
	11-1/4 Deg. GKT x GKT PVC Bend		
	Fitting Installation Labor		
	No Restraint		
	12" 11-1/4 Deg. Elbow GKT x GKT PVC DR-18 CS		
	11-1/4 Deg. GKT x GKT PVC Bend		
	Fitting Installation Labor		
	No Restraint		
<u></u>	14" 11-1/4 Deg. Elbow GKT x GKT PVC DR-18 CS		
	11-1/4 Deg. GKT x GKT PVC Bend		
	Fitting Installation Labor		
	No Restraint		
<u></u>	16" 11-1/4 Deg. Elbow GKT x GKT PVC DR-18 C9		
	11-1/4 Deg. GKT x GKT PVC Bend		
	Fitting Installation Labor		
	No Restraint		
	2-1/2 Deg. Elbow		
	4" 22-1/2 Deg. Elbow GKT x GKT PVC DR-18 C90		
	22-1/2 Deg. GKT x GKT PVC Bend		
	Fitting Installation Labor		
	No Restraint		
	6" 22-1/2 Deg. Elbow GKT x GKT PVC DR-18 C90		
	22-1/2 Deg. GKT x GKT PVC Bend		
	No Restraint		
`	Fitting Installation Labor		
P	8" 22-1/2 Deg. Elbow GKT x GKT PVC DR-18 C90		
	22-1/2 Deg. GKT x GKT PVC Bend		
	Fitting Installation Labor		
	No Restraint		
	10" 22-1/2 Deg. Elbow GKT x GKT PVC DR-18 C9		
	22-1/2 Deg. GKT x GKT PVC Bend		
	Fitting Installation Labor		
















ame		Description	Color
	⊕ 8x4 Cross PVC SOC x SOC DR-18 C900		
	8x4 Cross PVC SOC x SOC DR-18 C900		
	··· 📦 No Restraint		
	Fitting Installation Labor		
	8x6 Cross PVC SOC x SOC DR-18 C900		
	8x6 Cross PVC SOC x SOC DR-18 C900		
	■ No Restraint		
	Fitting Installation Labor		
	8x8 Cross PVC SOC x SOC DR-18 C900		
	■ 8x8 Cross PVC SOC x SOC DR-18 C900		
	No Restraint		
	Fitting Installation Labor		
	10x4 Cross PVC SOC x SOC DR-18 C900		
	10x4 Cross PVC SOC x SOC DR-18 C900		
	No Restraint		
	Fitting Installation Labor		
	10x6 Cross PVC SOC x SOC DR-18 C900		
	10x6 Cross PVC SOC x SOC DR-18 C900		
	No Restraint		
	Fitting Installation Labor		
	10x8 Cross PVC SOC x SOC DR-18 C900		
	10x8 Cross PVC SOC x SOC DR-18 C900		
	No Restraint		
	Fitting Installation Labor		
	10x10 Cross PVC SOC x SOC DR-18 C900		
	10x10 Cross PVC SOC x SOC DR-18 C900		
	No Restraint		
	Fitting Installation Labor		
	12x4 Cross PVC SOC x SOC DR-18 C900		
	12x4 Cross PVC SOC x SOC DR-18 C900		
	No Restraint		
	Fitting Installation Labor		
	12x6 Cross PVC SOC x SOC DR-18 C900		
	12x6 Cross PVC SOC x SOC DR-18 C900		
	Fitting Installation Labor		
	12x8 Cross PVC SOC x SOC DR-18 C900		
	22x8 Cross PVC SOC x SOC DR-18 C900		
	No Restraint		
	Fitting Installation Labor		
	12x10 Cross PVC SOC x SOC DR-18 C900		
	12x10 Cross PVC SOC x SOC DR-18 C900		
	No Restraint		
	Fitting Installation Labor		



	Description	Color
🖃 🧀 Plugs and Caps		
□ • 4" PVC Cap G DR-18 C900		
4" PVC Cap G DR-18 C900		
■ No Restraint		
Fitting Installation Labor		
□ 6 PVC Cap G DR-18 C900		
● 6" PVC Cap G DR-18 C900		
── ■ No Restraint		
Fitting Installation Labor		
⊕ 8" PVC Cap G DR-18 C900		
■ 8" PVC Cap G DR-18 C900		
No Restraint		
Fitting Installation Labor		
□ 10" PVC Cap G DR-18 C900		
□ 10" PVC Cap G DR-18 C900		
No Restraint		
Fitting Installation Labor		
12" PVC Cap G DR-18 C900		
12" PVC Cap G DR-18 C900		
No Restraint		
Fitting Installation Labor		
☐ • 14" PVC Cap G DR-18 C900		
14" PVC Cap G DR-18 C900		
No Restraint		
Fitting Installation Labor		
☐ 6" PVC Cap G DR-18 C900		
16" PVC Cap G DR-18 C900		
··· ■ No Restraint		
Fitting Installation Labor		
□ 18" PVC Cap G DR-18 C900		
18" PVC Cap G DR-18 C900		
··· ◎ No Restraint		
Fitting Installation Labor		
□ 20" PVC Cap G DR-18 C900		
■ 20" PVC Cap G DR-18 C900		
Fitting Installation Labor		
□ 22" PVC Cap G DR-18 C900		
22" PVC Cap G DR-18 C900		
No Restraint		
Fitting Installation Labor		
□ 24" PVC Cap G DR-18 C900		
■ 24" PVC Cap G DR-18 C900		
No Restraint		
Fitting Installation Labor		





Name		Description	Color
⊟	5" 11-1/4 Deg. Bend TJ x TJ DIP C250		
	11-1/4 Deg. TJ x TJ DIP Bend		
	No Restraint		
	Fitting Installation Labor		
	3" 11-1/4 Deg. Bend TJ x TJ DIP C250		
	11-1/4 Deg. TJ x TJ DIP Bend		
	Fitting Installation Labor		
	No Restraint		
⊟	10" 11-1/4 Deg. Bend TJ x TJ DIP C250		
	11-1/4 Deg. TJ x TJ DIP Bend		
	Fitting Installation Labor		
	No Restraint		
□ .•• [12" 11-1/4 Deg. Bend TJ x TJ DIP C250		
	■ 11-1/4 Deg. TJ x TJ DIP Bend		
	Fitting Installation Labor		
	No Restraint		
	14" 11-1/4 Deg. Bend TJ x TJ DIP C250		
T • L	11-1/4 Deg. TJ x TJ DIP Bend		
	Fitting Installation Labor		
	No Restraint		
	16" 11-1/4 Deg. Bend TJ x TJ DIP C250		
	11-1/4 Deg. TJ x TJ DIP Bend		
	Fitting Installation Labor		
	No Restraint		
⊡ (1 22-1	/2 Deg. Bends		
	3" 22-1/2 Deg. Bend TJ x TJ DIP C250		
	22-1/2 Deg. TJ x TJ DIP Bend		
	Fitting Installation Labor		
9			
	No Restraint		
	4" 22-1/2 Deg. Bend TJ x TJ DIP C250		
	22-1/2 Deg. TJ x TJ DIP Bend		
	Fitting Installation Labor		
	No Restraint		
<u> </u>	5" 22-1/2 Deg. Bend TJ x TJ DIP C250		
	22-1/2 Deg. TJ x TJ DIP Bend		
	No Restraint		
_`	Fitting Installation Labor		
□ □ □ □ 0	3" 22-1/2 Deg. Bend TJ x TJ DIP C250		
	22-1/2 Deg. TJ x TJ DIP Bend		
	Fitting Installation Labor		
	No Restraint		
□ 1	10" 22-1/2 Deg. Bend TJ x TJ DIP C250		
	22-1/2 Deg. TJ x TJ DIP Bend		
	Fitting Installation Labor		
	No Restraint		

Name	Description	Color
☐ • 12" 22-1/2 Deg. Bend TJ x TJ DIP C250		
22-1/2 Deg. TJ x TJ DIP Bend		
Fitting Installation Labor		
☐ • 14" 22-1/2 Deg. Bend TJ x TJ DIP C250		
□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□		
Fitting Installation Labor		
── ◎ No Restraint		
☐ • 16" 22-1/2 Deg. Bend TJ x TJ DIP C250		
□ 22-1/2 Deg. TJ x TJ DIP Bend		
Fitting Installation Labor		
□ No Restraint		
🗇 🧀 30 Deg. Bends		
□ 3" 30 Deg. Bend TJ x TJ DIP C250		
30 Deg. TJ x TJ DIP Bend		
Fitting Installation Labor		
No Restraint		
□ 4" 30 Deg. Bend TJ x TJ DIP C250		
30 Deg. TJ x TJ DIP Bend		
Fitting Installation Labor		
No Restraint		
⊟ 🔓 • 6" 30 Deg. Bend TJ x TJ DIP C250		
30 Deg. TJ x TJ DIP Bend		
■ No Restraint		
Fitting Installation Labor		
⊟ 🖁 • 8" 30 Deg. Bend TJ x TJ DIP C250		
30 Deg. TJ x TJ DIP Bend		
Fitting Installation Labor		
No Restraint		
□ 10" 30 Deg. Bend TJ x TJ DIP C250		
■ 30 Deg. TJ x TJ DIP Bend		
Fitting Installation Labor		
No Restraint		
☐ 12" 30 Deg. Bend TJ x TJ DIP C250		
■ 30 Deg. TJ x TJ DIP Bend		
Fitting Installation Labor		
No Restraint		
□ 14" 30 Deg. Bend TJ x TJ DIP C250		
30 Deg. TJ x TJ DIP Bend		
Fitting Installation Labor		
No Restraint		
□ 16" 30 Deg. Bend TJ x TJ DIP C250		
30 Deg. TJ x TJ DIP Bend		
Fitting Installation Labor		
No Restraint		
ino kestraint		


lame		Description	Color
	🖨 🧀 45 Deg. Bends		
	☐ 3" 45 Deg. Bend TJ x TJ DIP C250		
	── 🎒 45 Deg. TJ x TJ DIP Bend		
	Fitting Installation Labor		
	No Restraint		
	☐ • 4" 45 Deg. Bend TJ x TJ DIP C250		
	45 Deg. TJ x TJ DIP Bend		
	Fitting Installation Labor		
	No Restraint		
	□ • 6" 45 Deg. Bend TJ x TJ DIP C250		
	45 Deg. TJ x TJ DIP Bend		
	No Restraint		
	Fitting Installation Labor		
	8" 45 Deg. Bend TJ x TJ DIP C250		
	45 Deg. TJ x TJ DIP Bend		
	Fitting Installation Labor		
	No Restraint		
	□ 10" 45 Deg. Bend TJ x TJ DIP C250		
	45 Deg. TJ x TJ DIP Bend		
	Fitting Installation Labor		
	No Restraint		
	12" 45 Deg. Bend TJ x TJ DIP C250		
	■ 45 Deg. TJ x TJ DIP Bend		
	Fitting Installation Labor		
	No Restraint		
	□ 14" 45 Deg. Bend TJ x TJ DIP C250		
	■ 45 Deg. TJ x TJ DIP Bend		
	Fitting Installation Labor		
	No Restraint		
	□ • 16" 45 Deg. Bend TJ x TJ DIP C250		
	•		
	45 Deg. TJ x TJ DIP Bend		
	Fitting Installation Labor		
	No Restraint		
	60 Deg. Bends 3" 60 Deg. Bend TJ x TJ DIP C250		
	60 Deg. TJ x TJ DIP Bend Fitting Installation Labor		
	No Restraint		
	4" 60 Deg. Bend TJ x TJ DIP C250		
	60 Deg. TJ x TJ DIP Bend		
	Fitting Installation Labor		
	No Restraint		
	⊟ 6 6 60 Deg. Bend TJ x TJ DIP C250		
	60 Deg. TJ x TJ DIP Bend		
	No Restraint		
	Fitting Installation Labor		








Name	Description	Color
⊕ 6x4 TEE DIP TJ x TJ C250		
Fitting Installation Labor		
□ 6x6 TEE DIP TJ x TJ C250		
6x6 TEE DIP TJ x TJ C250		
Fitting Installation Labor		
8x4 TEE DIP TJ x TJ C250		
■ 8x4 TEE DIP TJ x TJ C250		
™ 🧊 No Restraint		
Fitting Installation Labor		
□ • 8x6 TEE DIP TJ x TJ C250		
8x6 TEE DIP TJ x TJ C250		
■ No Restraint		
Fitting Installation Labor		
□ • 8x8 TEE DIP TJ x TJ C250		
■ 8x8 TEE DIP TJ x TJ C250		
Fitting Installation Labor		
□ : • 10x4 TEE DIP TJ x TJ C250		
□ 10x4 TEE DIP TJ x TJ C250		
Fitting Installation Labor		
□ 0x6 TEE DIP TJ x TJ C250		
◎ No Restraint		
Fitting Installation Labor		
□ : • 10x8 TEE DIP TJ x TJ C250		
□ 10x8 TEE DIP TJ x TJ C250		
◎ No Restraint		
Fitting Installation Labor		
☐ : • 10x10 TEE DIP TJ x TJ C250		
■ 10x10 TEE DIP TJ x TJ C250		
Fitting Installation Labor		
12x4 TEE DIP TJ x TJ C250		
12x4 TEE DIP TJ x TJ C250		
··· 🥮 No Restraint		
Fitting Installation Labor		
□ 12x6 TEE DIP TJ x TJ C250		
12x6 TEE DIP TJ x TJ C250		
◎ No Restraint		
Fitting Installation Labor		




Name	Description	Color
□ 0x4 Cross DIP TJ x TJ C250		
■ 10x4 Cross DIP TJ x TJ C250		
■ No Restraint		
Fitting Installation Labor		
□ 10x6 Cross DIP TJ x TJ C250		
10x6 Cross DIP TJ x TJ C250		
No Restraint		
Fitting Installation Labor		
□ 10x8 Cross DIP TJ x TJ C250		
10x8 Cross DIP TJ x TJ C250		
No Restraint		
Fitting Installation Labor		
10x10 Cross DIP TJ x TJ C250		
■ 10x10 Cross DIP TJ x TJ C250		
No Restraint		
Fitting Installation Labor		
12x4 Cross DIP TJ x TJ C250		
12x4 Cross DIP TJ x TJ C250		
No Restraint		
Fitting Installation Labor		
□ 12x6 Cross DIP TJ x TJ C250		
12x6 Cross DIP TJ x TJ C250		
No Restraint		
Fitting Installation Labor		
12x8 Cross DIP TJ x TJ C250		
12x8 Cross DIP TJ x TJ C250		
No Restraint		
Fitting Installation Labor		
□ 12x10 Cross DIP TJ x TJ C250		
□ 12x10 Cross DIP TJ x TJ C250		
No Restraint		
Fitting Installation Labor		
□ 12x12 Cross DIP TJ x TJ C250		
■ 12x12 Cross DIP TJ x TJ C250		
No Restraint		
Fitting Installation Labor		
Reducers		
⊕ 6x4 Reducer DIP TJ x TJ C250		
6x4 Reducer DIP TJ x TJ C250		
No Restraint		
Fitting Installation Labor		
□ 6x4 Reducer DIP TJ x TJ C250		
6x4 Reducer DIP TJ x TJ C250		
™ S No Restraint		
Fitting Installation Labor		





Site Utility—Fire Assemblies



Site Utility—Sewer Assemblies



Name		Description	Color
	48" PVC SDR 35 GKT	48" PVC SDR 35 GKT	
j	48" x 20' PVC SDR 35 GKT	48" x 20' PVC SDR 3	
	Pipe Laying Labor		
□ 🛅 HDI	V		
	4" HDPE DR 21 C906 GKT	4" HDPE DR 21 C906	
ļ	4" x 40' HDPE DR 21 C906 GKT	4" x 40' HDPE DR 21	
	Pipe Laying Labor		
⊟ I-1	6" HDPE DR 21 C906 GKT	6" HDPE DR 21 C906	
		6" x 40' HDPE DR 21	
	Pipe Laying Labor		
	8" HDPE DR 21 C906 GKT	8" HDPE DR 21 C906	
ļ	8" x 40' HDPE DR 21 C906 GKT	8" x 40' HDPE DR 21	
	Pipe Laying Labor		
	10" HDPE DR 21 C906 GKT	10" HDPE DR 21 C9(
	10" x 40' HDPE DR 21 C906 GKT	10" x 40' HDPE DR 2	
	Pipe Laying Labor		
	12" HDPE DR 21 C906 GKT	12" HDPE DR 21 C9(
j	12" x 40' HDPE DR 21 C906 GKT	12" x 40' HDPE DR 2	
	Pipe Laying Labor		
	14" HDPE DR 21 C906 GKT	14" HDPE DR 21 C90	
ļ	14" x 40' HDPE DR 21 C906 GKT	14" x 40' HDPE DR 2	
ļ	Pipe Laying Labor		
	16" HDPE DR 21 C906 GKT	16" HDPE DR 21 C90	
}	16" x 40' HDPE DR 21 C906 GKT	16" x 40' HDPE DR 2	
\	Pipe Laying Labor		
	18" HDPE DR 21 C906 GKT	18" HDPE DR 21 C9(
	18" x 40' HDPE DR 21 C906 GKT	18" x 40' HDPE DR 2	
\	Pipe Laying Labor		
	20" HDPE DR 21 C906 GKT	20" HDPE DR 21 C90	
	20" x 40' HDPE DR 21 C906 GKT	20" x 40' HDPE DR 2	
	Pipe Laying Labor		
	24" HDPE DR 21 C906 GKT	24" HDPE DR 21 C9(
···	24" x 40' HDPE DR 21 C906 GKT	24" x 40' HDPE DR 2	
	Pipe Laying Labor		
	30" HDPE DR 21 C906 GKT	30" HDPE DR 21 C90	
	30" x 40' HDPE DR 21 C906 GKT	30" x 40' HDPE DR 2	
	Pipe Laying Labor		
		36" HDPE DR 21 C90	
	36" x 40' HDPE DR 21 C906 GKT	36" x 40' HDPE DR 2	
	Pipe Laying Labor	4-2	
	42" HDPE DR 21 C906 GKT	42" HDPE DR 21 C90	
	42" x 40' HDPE DR 21 C906 GKT	42" x 40' HDPE DR 2	
	Pipe Laying Labor	401110000000000000000000000000000000000	
	48" HDPE DR 21 C906 GKT	48" HDPE DR 21 C90	
	48" x 40' HDPE DR 21 C906 GKT	48" x 40' HDPE DR 2	
	Pipe Laying Labor		



Name		Description	Color
🖃 🧰 Manho	oles		
□ • 48	" Manhole		
	48" Dia. x 36" H Round Base		
👊	48" Dia. x 24" H Round Riser		
👛	48" Dia. Cone Roof w/ 24" Concentric Opening		
🝙	24" x 3" Grade Ring		
a	24" Ring and Cover		
<i>§</i>	Manhole Installation Labor		
	* Manhole		
	54" Dia. x 36" H Round Base		
a	54" Dia. x 24" H Round Riser		
a	54" Dia. Cone Roof w/ 24" Concentric Opening		
6	24" x 3" Grade Ring		
6	24" Ring and Cover		
	Manhole Installation Labor		
□ : • 60	"Manhole		
	60" Dia. x 36" H Round Base		
🝙	60" Dia. x 24" H Round Riser		
💼	60" Dia. Cone Roof w/ 24" Concentric Opening		
💼	24" x 3" Grade Ring		
	24" Ring and Cover		
	Manhole Installation Labor		
□ • 72	2" Manhole		
•	72" Dia. x 36" H Round Base		
	72" Dia. x 24" H Round Riser		
	72" Dia. Cone Roof w/ 24" Concentric Opening		
	24" x 3" Grade Ring		
	24" Ring and Cover		
	Manhole Installation Labor		
⊟ . 84	* Manhole		
• •	84" Dia. x 36" H Round Base		
	84" Dia. x 24" H Round Riser		
	84" Dia. Cone Roof w/ 24" Concentric Opening		
	24" x 3" Grade Ring		
	24" Ring and Cover		
	Manhole Installation Labor		
	* Manhole		
- 30	96" Dia. x 36" H Round Base		
	96" Dia. x 24" H Round Riser		
	96 Dia. X 24 H Round Riser 96 Dia. Cone Roof w/ 24 Concentric Opening		
	24" x 3" Grade Ring		
	24" Ring and Cover		
	Manhole Installation Labor		




ame		Description	Color
Ė	• 10" 11-1/4 Deg. Elbow SOC x SOC PVC SDR 35	;	
	11-1/4 Deg. SOC x SOC PVC Bend		
	Fitting Installation Labor		
	No Restraint		
<u> </u>	• 12" 11-1/4 Deg. Elbow SOC x SOC PVC SDR 35	;	
	11-1/4 Deg. SOC x SOC PVC Bend		
	···· 🌽 Fitting Installation Labor		
	No Restraint		
<u> </u>	• 14" 11-1/4 Deg. Elbow SOC x SOC PVC SDR 35	;	
	11-1/4 Deg. SOC x SOC PVC Bend		
	Fitting Installation Labor		
	No Restraint		
<u> </u>	• 16" 11-1/4 Deg. Elbow SOC x SOC PVC SDR 35	;	
	■ 11-1/4 Deg. SOC x SOC PVC Bend		
	Fitting Installation Labor		
	No Restraint		
	22-1/2 Deg. Elbow		
	• 4" 22-1/2 Deg. Elbow SOC x SOC PVC SDR 35		
	22-1/2 Deg. SOC x SOC PVC Bend		
	Fitting Installation Labor		
	No Restraint		
	6" 22-1/2 Deg. Elbow SOC x SOC PVC SDR 35		
	22-1/2 Deg. SOC x SOC PVC Bend		
	No Restraint		
	Fitting Installation Labor		
<u> </u>	8" 22-1/2 Deg. Elbow SOC x SOC PVC SDR 35		
	22-1/2 Deg. SOC x SOC PVC Bend		
	Fitting Installation Labor		
	No Restraint		
₽.	• 10" 22-1/2 Deg. Elbow SOC x SOC PVC SDR 35	;	
	22-1/2 Deg. SOC x SOC PVC Bend		
	Fitting Installation Labor		
	No Restraint		
<u> </u>	• 12" 22-1/2 Deg. Elbow SOC x SOC PVC SDR 35	;	
	22-1/2 Deg. SOC x SOC PVC Bend		
	Fitting Installation Labor		
	No Restraint		
<u> </u>	• 14" 22-1/2 Deg. Elbow SOC x SOC PVC SDR 35	;	
	22-1/2 Deg. SOC x SOC PVC Bend		
	Fitting Installation Labor		
	No Restraint		
	• 16" 22-1/2 Deg. Elbow SOC x SOC PVC SDR 35	;	
	22-1/2 Deg. SOC x SOC PVC Bend		
	Fitting Installation Labor		
	No Restraint		











Name		Description	Color
	⊕ 8x6 WYE PVC SOC x SOC SDR 35		
	8x6 WYE PVC SOC x SOC SDR 35		
	■ No Restraint		
	Fitting Installation Labor		
	⊕ • 8x8 WYE PVC SOC x SOC SDR 35		
	8x8 WYE PVC SOC x SOC SDR 35		
	No Restraint		
	Fitting Installation Labor		
	□ 10x4 WYE PVC SOC x SOC SDR 35		
	10x4 WYE PVC SOC x SOC SDR 35		
	No Restraint		
	Fitting Installation Labor		
	10x6 WYE PVC SOC x SOC SDR 35		
	10x6 WYE PVC SOC x SOC SDR 35		
	No Restraint		
	Fitting Installation Labor		
	10x8 WYE PVC SOC x SOC SDR 35		
	10x8 WYE PVC SOC x SOC SDR 35		
	No Restraint		
	Fitting Installation Labor		
	10x10 WYE PVC SOC x SOC SDR 35		
	10x10 WYE PVC SOC x SOC SDR 35		
	No Restraint		
	Fitting Installation Labor		
	12x4 WYE PVC SOC x SOC SDR 35		
	12x4 WYE PVC SOC x SOC SDR 35		
	No Restraint		
	Fitting Installation Labor		
	12x6 WYE PVC SOC x SOC SDR 35		
	12x6 WYE PVC SOC x SOC SDR 35		
	No Restraint		
	Fitting Installation Labor		
	12x8 WYE PVC SOC x SOC SDR 35		
	12x8 WYE PVC SOC x SOC SDR 35		
	No Restraint		
	Fitting Installation Labor		
	12x10 WYE PVC SOC x SOC SDR 35		
	12x10 WYE PVC SOC x SOC SDR 35		
	No Restraint		
	Fitting Installation Labor		
	12x12 WYE PVC SOC x SOC SDR 35		
	• •		
	12x12 WYE PVC SOC x SOC SDR 35		
	No Restraint		
	Fitting Installation Labor		












Name		Description	Color
□ 14'	Sewer Cleanout		
🟐	14" Sewer Cleanout		
<i>}</i>	Cleanout Install Labor		
⊟ • 16"	Sewer Cleanout		
🟐	16" Sewer Cleanout		
<i>§</i>	Cleanout Install Labor		

Site Utility—Drainage




Name	Description	Color
⊟ 148" PVC SDR 35 GKT	48" PVC SDR 35 GKT	
48" x 20' PVC SDR 35 GKT	48" x 20' PVC SDR 3	
Pipe Laying Labor		
□ hDPE		
□ 1-1 4" HDPE DR 21 C906 GKT	4" HDPE DR 21 C906	
4" x 40' HDPE DR 21 C906	5 GKT 4" x 40' HDPE DR 21	
Pipe Laying Labor		
6" HDPE DR 21 C906 GKT	6" HDPE DR 21 C906	
6" x 40' HDPE DR 21 C906		
Pipe Laying Labor		
□ 1 8" HDPE DR 21 C906 GKT	8" HDPE DR 21 C906	
8" x 40' HDPE DR 21 C906		
Pipe Laying Labor		
□ I 10" HDPE DR 21 C906 GKT	10" HDPE DR 21 C90	
■ 10" x 40' HDPE DR 21 C90		
Pipe Laying Labor		
□ 12" HDPE DR 21 C906 GKT	12" HDPE DR 21 C90	
■ 12" x 40' HDPE DR 21 C90		
Pipe Laying Labor	ZE X IS TISTEDICE	
□ I 14" HDPE DR 21 C906 GKT	14" HDPE DR 21 C90	
■ 14" x 40' HDPE DR 21 C90		
Pipe Laying Labor	77 X 10 1101 Z 011 Z	
□ 16" HDPE DR 21 C906 GKT	16" HDPE DR 21 C90	
■ 16" x 40' HDPE DR 21 C90		
Pipe Laying Labor	20 % 10 1101 2 011 2	
□ I 18" HDPE DR 21 C906 GKT	18" HDPE DR 21 C90	
■ 18" x 40' HDPE DR 21 C90		
Pipe Laying Labor	20 X 10 TIDI E DICE	
□ 1 20" HDPE DR 21 C906 GKT	20" HDPE DR 21 C90	
② 20" x 40' HDPE DR 21 C90		
Pipe Laying Labor	20 X 10 1101 2 01 2	
24" HDPE DR 21 C906 GKT	24" HDPE DR 21 C90	
24" x 40' HDPE DR 21 C90		1
Pipe Laying Labor	21 X 10 1151 2 51 2	
□ [1] 30" HDPE DR 21 C906 GKT	30" HDPE DR 21 C90	
30 x 40' HDPE DR 21 C90		
Pipe Laying Labor	30 X 10 HDFL DK 2	
□ [•1 36" HDPE DR 21 C906 GKT	36" HDPE DR 21 C90	
36" x 40' HDPE DR 21 C90		
Pipe Laying Labor	JO X 40 TIDFE DR 2	
	42" HDPE DR 21 C90	
□ 42" HDPE DR 21 C906 GKT ■ 42" x 40' HDPE DR 21 C90		
	06 GKT 42" x 40' HDPE DR 2	
Pipe Laying Labor	40 [®] LIDDE DD 04 004	
48" HDPE DR 21 C906 GKT	48" HDPE DR 21 C90	
48" x 40' HDPE DR 21 C90	06 GKT 48" x 40' HDPE DR 2	
Pipe Laying Labor		

Name		Description	Color
Ē 🛅 N12	HDPE		
	4" HDPE DR 21 C906 GKT	4" HDPE DR 21 C906	
	# x 40' HDPE DR 21 C906 GKT	4" x 40' HDPE DR 21	
	Pipe Laying Labor		
	6" HDPE DR 21 C906 GKT	6" HDPE DR 21 C906	
	6" x 40' HDPE DR 21 C906 GKT	6" x 40' HDPE DR 21	
	Pipe Laying Labor		
	8" HDPE DR 21 C906 GKT	8" HDPE DR 21 C906	
	9 8" x 40' HDPE DR 21 C906 GKT	8" x 40' HDPE DR 21	
	Pipe Laying Labor		
	10" HDPE DR 21 C906 GKT	10" HDPE DR 21 C9(
ļ <u>.</u>	10" x 40' HDPE DR 21 C906 GKT	10" x 40' HDPE DR 2	
	Pipe Laying Labor		
	12" HDPE DR 21 C906 GKT	12" HDPE DR 21 C9(
ļ <u>.</u>	12" x 40' HDPE DR 21 C906 GKT	12" x 40' HDPE DR 2	
	Pipe Laying Labor		
	14" HDPE DR 21 C906 GKT	14" HDPE DR 21 C9(
	14" x 40' HDPE DR 21 C906 GKT	14" x 40' HDPE DR 2	
	Pipe Laying Labor		
	16" HDPE DR 21 C906 GKT	16" HDPE DR 21 C9(
	16" x 40' HDPE DR 21 C906 GKT	16" x 40' HDPE DR 2	
	Pipe Laying Labor		
	18" HDPE DR 21 C906 GKT	18" HDPE DR 21 C9(
	18" x 40' HDPE DR 21 C906 GKT	18" x 40' HDPE DR 2	
	Pipe Laying Labor		
	20" HDPE DR 21 C906 GKT	20" HDPE DR 21 C9(
	9 20" x 40' HDPE DR 21 C906 GKT	20" x 40' HDPE DR 2	
\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	Pipe Laying Labor		
	24" HDPE DR 21 C906 GKT	24" HDPE DR 21 C9(
	24" x 40' HDPE DR 21 C906 GKT	24" x 40' HDPE DR 2	
	Pipe Laying Labor		
	30" HDPE DR 21 C906 GKT	30" HDPE DR 21 C9(
	30" x 40' HDPE DR 21 C906 GKT	30" x 40' HDPE DR 2	
	Pipe Laying Labor		
	36" HDPE DR 21 C906 GKT	36" HDPE DR 21 C9(
	36" x 40' HDPE DR 21 C906 GKT	36" x 40' HDPE DR 2	
	Pipe Laying Labor		
	42" HDPE DR 21 C906 GKT	42" HDPE DR 21 C9(
	9 42" x 40' HDPE DR 21 C906 GKT	42" x 40' HDPE DR 2	
	Pipe Laying Labor		
	48" HDPE DR 21 C906 GKT	48" HDPE DR 21 C9(
	9 48" x 40' HDPE DR 21 C906 GKT	48" x 40' HDPE DR 2	
	Pipe Laying Labor		



Name		Description	Color
CMP (Corr. Metal)		ocsaripuori	COIOI
E 12" CMP 10ga CPL	6	12" CMP 10ga CPLG	
12 CMP 10ga CPI		12" x 20' CMP 10ga	
Pipe Laying Lab		12 X 20 CINF 109a	
□ 15" CMP 10ga CPI		15" CMP 10ga CPLG	
15" x 20' CMP 1		15" x 20' CMP 10ga	
Pipe Laying Lab		10 X 20 CMF 1090	
□ 18" CMP 10ga CPL		18" CMP 10ga CPLG	
■ 18" x 20' CMP 1		18" x 20' CMP 10ga	
₽ipe Laying Lab		10 X 20 0 1 10ga	
21" CMP 10ga CPL		21" CMP 10ga CPLG	
■ 21" x 20' CMP 1		21" x 20' CMP 10ga	
Pipe Laying Lab			
□ 11 24" CMP 10ga CPI		24" CMP 10ga CPLG	
□ 24" x 20' CMP 1		24" x 20' CMP 10ga	
Pipe Laying Lab			
□ 1 30" CMP 10ga CPI		30" CMP 10ga CPLG	
30" x 20' CMP 1		30" x 20' CMP 10ga	
Pipe Laying Lab			
□ 11 36" CMP 10ga CPI	.G	36" CMP 10ga CPLG	
36" x 20' CMP 1	.0ga CPLG	36" x 20' CMP 10ga	
Pipe Laying Lab	or		
□ 11 42" CMP 10ga CPI	.G	42" CMP 10ga CPLG	
■ 42" x 20' CMP 1	.0ga CPLG	42" x 20' CMP 10ga	
Pipe Laying Lab	or		
□ 11 48" CMP 10ga CPL	.G	48" CMP 10ga CPLG	
48" x 20' CMP 1	.0ga CPLG	48" x 20' CMP 10ga	
Pipe Laying Lab	or		
□ 1 54" CMP 10ga CPL	.G	54" CMP 10ga CPLG	
54" x 20' CMP 1	.0ga CPLG	54" x 20' CMP 10ga	
Pipe Laying Lab			
☐ 1 60" CMP 10ga CPL		60" CMP 10ga CPLG	
60" x 20' CMP 1		60" x 20' CMP 10ga	
Pipe Laying Lab			
⊟ [1] 66" CMP 10ga CPI		66" CMP 10ga CPLG	
66" x 20' CMP 1		66" x 20' CMP 10ga	
Pipe Laying Lab			
□ 1 72" CMP 10ga CPI		72" CMP 10ga CPLG	
─────────────────────────────────────		72" x 20' CMP 10ga	
Pipe Laying Lab			
⊟ 1 84" CMP 10ga CPl		84" CMP 10ga CPLG	
■ 84" x 20' CMP 1		84" x 20' CMP 10ga	
Pipe Laying Lab		0.01.01.01.01.01.01	
96" CMP 10ga CPI		96" CMP 10ga CPLG	
96" x 20' CMP 1		96" x 20' CMP 10ga	
Pipe Laying Lab	or		

Name		Description	Color
	102" CMP 10ga CPLG	102" CMP 10ga CPL	
	102" x 20' CMP 10ga CPLG	102" x 20' CMP 10ga	
i,	Pipe Laying Labor		
	108" CMP 10ga CPLG	108" CMP 10ga CPL	
	108" x 20' CMP 10ga CPLG	108" x 20' CMP 10ga	
ļ	Pipe Laying Labor		
	114" CMP 10ga CPLG	114" CMP 10ga CPL	
	114" x 20' CMP 10ga CPLG	114" x 20' CMP 10ga	
	Pipe Laying Labor		
	120" CMP 10ga CPLG	120" CMP 10ga CPLI	
····	120" x 20' CMP 10ga CPLG	120" x 20' CMP 10ga	
	Pipe Laying Labor		
	126" CMP 10ga CPLG	126" CMP 10ga CPLI	
	126" x 20' CMP 10ga CPLG	126" x 20' CMP 10ga	
i	Pipe Laying Labor		
	132" CMP 10ga CPLG	132" CMP 10ga CPL	
	132" x 20' CMP 10ga CPLG	132" x 20' CMP 10ga	
·	Pipe Laying Labor		
	138" CMP 10ga CPLG	138" CMP 10ga CPL	
	138" x 20' CMP 10ga CPLG	138" x 20' CMP 10ga	
·	Pipe Laying Labor		
	144" CMP 10ga CPLG	144" CMP 10ga CPLI	
	144" x 20' CMP 10ga CPLG	144" x 20' CMP 10ga	
	Pipe Laying Labor		
	(Corr. Plastic)		
	4" DIP Dual Wall IBJ	4" DIP Dual Wall IBJ	
	4" x 20' DIP Dual Wall IBJ	4" x 20' DIP Dual Wa	
	Pipe Laying Labor		
	6" DIP Dual Wall IBJ	6" DIP Dual Wall IBJ	
	6" x 20' DIP Dual Wall IBJ	6" x 20' DIP Dual Wa	
	Pipe Laying Labor		
	8" DIP Dual Wall IBJ	8" DIP Dual Wall IBJ	
	8" x 20' DIP Dual Wall IBJ	8" x 20' DIP Dual Wa	
	Pipe Laying Labor	10" DIP Dual Wall IB	
	10" DIP Dual Wall IBJ	10" x 20' DIP Dual Wall IB	
	10" x 20' DIP Dual Wall IBJ	10 X 20 DIP Dual VI	
⊟ ⊺ -	Pipe Laying Labor 12" DIP Dual Wall IBJ	12" DIP Dual Wall IB	
	12" x 20' DIP Dual Wall IBJ	12" x 20' DIP Dual W	
	Pipe Laying Labor	12 X 20 DIP Dual VI	
⊟ I =1	15" DIP Dual Wall IBJ	15" DIP Dual Wall IB	
	15" x 20' DIP Dual Wall IBJ	15" x 20' DIP Dual W	
	Pipe Laying Labor	13 X 20 DIF DUALVI	
⊟ [-	18" DIP Dual Wall IBJ	18" DIP Dual Wall IB	
	3 18" x 20' DIP Dual Wall IBJ	18" x 20' DIP Dual W	
	Pipe Laying Labor	10 X 20 DIF Dual VI	<u> </u>
	Fipe Laying Labor		<u> </u>





Name		Description	Color
Ė.	• 10" 22-1/2 Deg. Elbow SOC x SOC PVC SDR 3	5	
	22-1/2 Deg. SOC x SOC PVC Bend		
	Fitting Installation Labor		
	No Restraint		
Ė	12" 22-1/2 Deg. Elbow SOC x SOC PVC SDR 3	5	
	22-1/2 Deg. SOC x SOC PVC Bend		
	Fitting Installation Labor		
	No Restraint		
<u> </u>	• 14" 22-1/2 Deg. Elbow SOC x SOC PVC SDR 33	5	
	22-1/2 Deg. SOC x SOC PVC Bend	,	
	Fitting Installation Labor		
<u>i</u>	No Restraint	-	
—	• 16" 22-1/2 Deg. Elbow SOC x SOC PVC SDR 3	5	
	22-1/2 Deg. SOC x SOC PVC Bend		
	Fitting Installation Labor		
	No Restraint		
	30 Deg. Elbow		
₽	4" 30 Deg. Elbow SOC x SOC PVC SDR 35		
	30 Deg. SOC x SOC PVC Bend		
	Fitting Installation Labor		
	No Restraint		
- ⊟	• 6" 30 Deg. Elbow SOC x SOC PVC SDR 35		
	30 Deg. SOC x SOC PVC Bend		
	No Restraint		
	Fitting Installation Labor		
<u> </u>	8" 30 Deg. Elbow SOC x SOC PVC SDR 35		
	30 Deg. SOC x SOC PVC Bend		
	Fitting Installation Labor		
	No Restraint		
<u> </u>	10" 30 Deg. Elbow SOC x SOC PVC SDR 35		
	30 Deg. SOC x SOC PVC Bend		
	Fitting Installation Labor		
	No Restraint		
	12" 30 Deg. Elbow SOC x SOC PVC SDR 35		
	·		
	30 Deg. SOC x SOC PVC Bend		
	Fitting Installation Labor		
	No Restraint		
Ξ	• 14" 30 Deg. Elbow SOC x SOC PVC SDR 35		
	30 Deg. SOC x SOC PVC Bend		
	Fitting Installation Labor		
	No Restraint		
Ė	• 16" 30 Deg. Elbow SOC x SOC PVC SDR 35		
	30 Deg. SOC x SOC PVC Bend		
	Fitting Installation Labor		
	No Restraint		





